

ULTRA SILENT AQUARIUM AIR PUMP



USER MANUAL

Please read these instructions in their entirety before attempting to use this product.

SAFETY INSTRUCTIONS

DANGER – To avoid possible electric shock, special care should be taken since water is employed in the use of aquarium equipment. For each of the following situations, return the appliance to an

authorized service facility for service or discard the appliance.

WARNING – To guard against injury, basic safety precautions should be observed including the following:

IMPORTANT SAFETY INSTRUCTIONS

1. A. If the the air pump shows any sign of abnormal water leakage, immediately unplug it from the power source.

B. Carefully examine the the air pump after installation. It should not be plugged in if there is water on the parts not intended to be wet.

C. Do not operate the air pump if it has a damaged cord or plug, or if it is malfunctioning or if it is dropped or damaged in any manner.

D. To avoid the possibility of the the air pump' power

supply or electrical outlet getting wet, position aquarium stand and tank to one side of the wall mounted electrical outlet to prevent water from dripping onto the electrical outlet or plug. A "drip loop" should be arranged by the user for the cord connecting the air pump to the electrical outlet. The "drip loop" is the part of the cord below the level of the electrical outlet, or the connector if an extension cord is used, to prevent water travel along the cord and coming in contact with the electrical outlet. If the plug or the electrical outlets do get wet, DON'T unplug the cord. Disconnect the fuse to the circuit breaker that supplies power to the the air pump's electrical outlet. Then unplug and examine for the presence of water in the electrical outlet.

2. Close supervision is necessary when the air

pump is used by or near children.

3. To avoid injury, do not contact moving parts or hot parts such as heaters, reflectors, lamp bulbs, etc.

4. Always unplug the air pump power supply from the outlet when not in use, before putting on or taking off parts, and before cleaning. Never yank the cord to pull plug from the outlet. Grasp the plug and pull to disconnect.

5. Do not use the air pump for other than intended use. The use of attachments not recommended or sold by the air pump manufacturer Cambani may cause an unsafe condition.

6. Make sure the air pump is securely installed before operating it.

7. Care should be taken to arrange the cord so that it will not be tripped over or pulled.


INSTALLATION INSTRUCTIONS

1. Check air pump for any signs of shipping damage. If damaged, do not operate and return to place of purchase.

2. Place the Air Pump on flat surface on the outer side of the aquarium, using the suction cups included in the package.

3. Connect one end of the airline tubing (included in the package) to air outlet valves on the back of the unit, then secure tubing with braces, connect the other end of the airline tubing to the one end of the check valve then connect the other end of the check valve via tubing to the bubble stone.

4. Be sure that the cord makes a "drip loop" to prevent water from running



down and into the air pump plug or electrical outlet.

5. Plug in air pump.




Figure 1




Figure 2




Figure 4




Figure 3

CHECK VALVE INSTALLATION

Cut the air tubing off about two to four inches (5-10cm) from the air pump. Use sharp scissors and make sure the cut is straight. Insert the check valve into the air tubing attached to the aquarium air pump. Attach additional air tubing to the other end of the check valve. Refer to the image below for the right directions of check valve- left side lead to the air pump, right side to the air stone.

